# Solid state soft starter type VFS specification (rev.5)

#### Introduction

The solid state soft starter type VFS is designed to operate in conjunction with standard medium voltage squirrel cage motors (asynchronous and synchronous).

#### Motor voltage and frequency ratings

2300 V, 3300 V, 4160 V, 6000 V to 6900 V, 10000 V to 11000 V and 13800 V AC +10% to -15% @ 50/60 Hz.

### Power and current ratings

Up to 4850 kW @ 2300 V (max. 1400 A)

Up to 6950 kW @ 3300 V (max. 1400 A)

Up to 8750 kW @ 4160 V (max. 1400 A)

Up to 12650 kW @ 6000 V (max. 1400 A)

Up to 13900 kW @ 6600 V (max. 1400 A)

Up to 14550 kW @ 6900 V (max. 1400 A)

Up to 21050 kW @ 10000 V (max. 1400 A)

Up to 23200 kW @ 11000 V (max. 1400 A)

Up to 10400 kW @ 13800 V (max. 500 A)

## **Control voltage**

230 V AC +10% to -15% @ 50/60 Hz (standard)

110 V AC +10% to -15% @ 50/60 Hz (optional)

220 V DC +10% to -15% (optional)

110 V DC +10% to -15% (optional)

# Power frequency withstand test

System voltage	Test voltage
2300 V to 6900 V	20 kV
10000 V to 11000 V	28 kV
13800 V	38 kV

## Basic impulse level (BIL)

System voltage	BIL
2300 V to 6900 V	60 kV
10000 V to 11000 V	75 kV
13800 V	95 kV

#### Thyristor (SCR) peak inverse voltage rating

, (, , ,	
System voltage	PIV
2300 V	6900 V
3300 V	9900 V
4160 V	12500 V
6000 V to 6900 V	19500 V
10000 V to 11000 V	32500 V
13800 V	41000 V

#### Motor and soft starter protections

Starting to running transition (19)

Undervoltage (27)

Undercurrent (37)

Underpower (37) optional

Bearing RTD protection (38) optional

Mechanical condition protection (39) optional

Phase-balance current (46)

Phase loss (46)

Phase-sequence (47)

Incomplete sequence (48)

Locked rotor (48)

I<sup>2</sup>t electronic motor overload (49)

Stator RTD protection (49) optional

Instantaneous overcurrent (50)

Instantaneous earth overcurrent (50G)

AC inverse time overcurrent (51)

AC inverse time earth overcurrent (51G)

AC inverse time overcurrent/locked rotor (51LR)

Power factor protection (55) optional

Overvoltage (59)

Number of starts per hour (66)

Frequency protection (81) optional

Lockout (86)

Start inhibit (86)

External fault (94/95)

Shorted thyristor (SCR) protection

Thyristor (SCR) overtemperature protection

Transient voltage protection optional

# Acceleration and deceleration control

Initial Voltage, Current Limit, Dual Adjustment, Pulse Start and Soft Stop are only a few of the integrated acceleration and deceleration functions in our solid state soft starter type VFS, which allows the user to control the motor during start and stop.

#### Operator interface device (HMI)

Keypad for programing and monitoring with a 2 lines x 16 characters backlighted LCD and 8 status LEDs (ON, Test, Dual Adjustment, Fault, Start, Run, Soft Stop and Stop).

#### **Communications**

RS485 with MODBUS RTU protocol is standard. RS232 port and other communication protocols like

MODBUS TCP or PROFIBUS DP are available on request.

#### Statistical and fault data

The fault log contains the last 10 events with error description. Last starting time, last maximum starting current, last trip current, total run time, total number of starts and total number of trips are available as statistical data.

#### Panel design

The standard panel is designed to meet IP4X according to IEC 60529 with cable entrance from bottom. The panel structure is made of galvanised sheet metal and the covers and doors are powder-coated with RAL7035. Higher IP codes, different panel colours and cable entrance from top are available on request.

#### **Ambient conditions**

The solid state soft starter type VFS is designed to operate under the ambient temperature range of 0 °C to 50 °C (-20 °C to 50 °C as an option), a relative air humidity of  $\leq$ 95% non-condensing and an altitude of  $\leq$ 1000 m above sea level without derating.

#### Approvals, certificates and standards

The solid state soft starter type VFS is type approved according to IEC 62271-200 and will be manufactured in compliance with IEC standards, the EC directives and the ISO 9001 standard. Individual approvals by ABS, BV, CCS, DNV-GL, LRS, RINA, RS, etc. are available on request.

Please contact <a href="mailto:salessupport@mocotech.de">salessupport@mocotech.de</a> for any further information.





Mocotech GmbH Nordring 20 47495 Rheinberg Germany Tel: +49 (0) 2843 90488 0 Fax: +49 (0) 2843 90488 44 Bank account details Volksbank an der Niers eG IBAN: DE89 3206 1384 0208 6700 18 BIC/SWIFT: GENO DE D1GDL VAT reg. no.: DE210923736 HRB Kleve 8245 CEO: Simon Heimbach